Enabled dual camera (Raspberry pi 5)

When you can only see one of both cameras:

rpicam-hello --list-cameras

https://docs.arducam.com/Raspberry-Pi-Camera/Pivariety-Camera/Libcamera-User-Guide/#introduction 123 to do:

```
install_pivariety_pkgs.sh -p libcamera_dev
install_pivariety_pkgs.sh -p libcamera_apps
install_pivareity_pkgs.sh -p kernel_driver
```

Revision #5
Created 17 May 2026 07:29:08 by Tim
Updated 17 May 2026 08:48:18 by Tim