

# error

# 0x105(ESP\_ERR\_NOT\_FOUN D)


This error can mean either:

- The camera isn't seated properly
- The pin configuration is wrong
- You've selected the wrong board

```
E (893) camera: Camera probe failed with error 0x105(ESP_ERR_NOT_FOUND)
Camera init failed with error 0x105
```

In the case of the ESP32-S3-WROOM, selecting WROOM2 generates this error.

These settings work properly:



Revision #1

Created 25 September 2024 05:42:10 by Tim

Updated 25 September 2024 06:05:06 by Tim